



MEASURING FOR RADIATOR ENCLOSURES

LENGTH:

Measure beyond the valves and pipes on both ends.

HEIGHT:

Measure from the floor to the top of the radiator.

DEPTH:

Measure from the wall to the front of the radiator.

NOTE: A minimum of 1 inch clearance on length and height, and 1½ inch clearance on depth is necessary for proper fit.

